

# **Mountain Buggy Tire Pump Instructions**

1. Remove nozzle from the black end of the pump.
2. Screw onto the long silver end of the pump.
3. Remove the cap on the tire.
4. Screw the nozzle onto the tire.
5. Inflate until the tire is firm, but you can push it in with your thumb.